


1000V GV350 Series Automotive Contactor



## **FEATURES**

Sas filled design offers lower resistance than non-hermetic switches resulting in higher system efficiency and less heat generation.

- Suppression gas allows high fault interrupt capability and prohibits oxidation.
- Smaller, lighter, and more efficient than non-hermetic switches.
- > Optional auxiliary contacts for dependable feedback for HVIL circuits.
- > Optional joint resistance and voltage sensing pins for easy system diagnosis.

# ADVANCED SWITCHING SOLUTIONS



# **PRODUCT SPECIFICATIONS**

Specifications	Units	Data	
Rated Voltage <sup>6</sup>	V	1000	
Nominal Current	A	500	
Contact Arrangement			
Main	Form X	SPST-NO	
Auxiliary <sup>1</sup>	Form A or B	SPST-NO or SPST-NC	
Mechanical Life	cycles	1,000,000	
Contact Resistance			
Max	mohms	0.2	
Typical	mohms	0.15	
Insulation Resistance <sup>2</sup>	Mohms	100	6
Dielectric at sea level (leakage < 1mA)	VRMS	4000	
Shock, 1/2 Sine, 11ms			
Actuated (closed)	G	50	
Non Actuated (open)	G	25	
Vibration, Sinusoidal (10-2000 Hz peak)	G	25	
Environmental Seal	Exceeds IP	Exceeds IP67 & IP69K	
Salt Fog	MIL-ST	MIL-STD-810	
Short Circuit Current (20ms)	A	4000	
Max Break Current @ 400V (1 cycle)	A	3000	
Max Break Current @ 800V (1 cycle)	A	900	

# POWER SWITCHING AND CURRENT CARRY RATINGS

#### 1,000,000 100,000 10,000 1,

### **DC POWER SWITCHING CYCLES**

**CURRENT CARRY vs TIME** 


-24V -

-300V -450V -600V -800V

# COIL RATINGS at 25°C

Coil P/N Designation	Р	R	
Coil Voltage, Nominal (VDC)	12/24	12/24	
Coil Type	External PWM <sup>4</sup>		
Coil Resistance (ohms)	1.45	5	
Operate Time, Max (ms) <sup>5</sup>	20		
Release Time, Max (ms)	12		


with 85°C terminal temperature rise



CURRENT (A)

# ADVANCED SWITCHING SOLUTIONS


# **UPRIGHT MOUNT DIMENSIONS**



PIK-AS Austria GmbH | Elektrotechnische Fabrikate | AT-7433 Mariasdorf Tel.: +43 3353 7613 | Fax: +43 3353 7612 | office@pikas.at | www.pikas.at


# SIDE MOUNT DIMENSIONS





Side Mount (Auxiliary Shown) T1 X1 X2 T2

<u>Side Mount</u> (Auxiliary with Main Terminal Connection for Sensing Voltage Across Contacts or Bolted Joint Resistance Shown)



PIK-AS Austria GmbH | Elektrotechnische Fabrikate | AT-7433 Mariasdorf Tel.: +43 3353 7613 | Fax: +43 3353 7612 | office@pikas.at | www.pikas.at

# **SPECIFICATIONS**

#### **Coil/Auxiliary Connector**

Coil: Tin Plated Brass Auxiliary: Tin Plated Beryllium Copper

#### Mounting

M5 or No. 10 Screws Torque 1.7-4 Nm [15-35 in-lb]

#### **Power Connection**


Silver Plated Copper M8x1.25 Terminals Torque 10 Nm [90 in-lb] max

#### **Auxiliary Contacts**

(Optional)



### **Power Contacts**



#### **Temperature and Weight**

Operating ambient Temp Range = -55 to  $+85^{\circ}C^{3}$ Storage ambient Temp Range = -70 to  $+150^{\circ}C$ Weight, typical = 0.39 kg (0.86 lb)

#### Packaging

24 units per shipping box 21 in x 18 in x 4 in shipping box

PIK-AS Austria GmbH | Elektrotechnische Fabrikate | AT-7433 Mariasdorf Tel.: +43 3353 7613 | Fax: +43 3353 7612 | office@pikas.at | www.pikas.at

# PART NUMBER SYSTEM

GV35	1	Ρ	Р	В
Mounting	<b>1</b> = Upright			
	<b>2</b> = Side Mount			
Coil Voltage		<b>P</b> = 12/24 Vdc <sup>4</sup>	]	
		<b>R</b> = 12/24 Vdc <sup>4</sup>	]	
Coil Termination			<b>P</b> = Pins	
Auxiliary				X = None
Contacts				<b>B</b> = SPST-NO Normally Open

# **APPLICATION NOTES**

• Power switching lifecycles are based on <u>current flow</u> from A1(+) to A2(-). For best breaking performance, the contactor should be installed so that current flows from A1(+) to A2(-). There are cases where the contactor will interrupt power in the opposite direction but please contact GIGAVAC to confirm suitability. Direction of current flow is not relevant during make or when flowing on closed contacts. For bi-directional contactors, please contact GIGAVAC.

• Applications with capacitors will require a pre-charge circuit.

• Electrical life rating is based on resistive load with 27µH maximum inductance in circuit. Because your application may be different, we suggest you test the contactor in your circuit to verify life is as required.

• End of life is defined as when the dielectric, insulation resistance or contact resistance exceeds the specifications listed.

#### **Notes & Definitions:**

**1** Auxiliary contact rating is 2A, 24Vdc Resistive load, 100,000 cycles. Minimum current is 0.1mA, 5V. The auxiliary contact is mechanically linked to the main power contacts.

**2** Insulation resistance is 50 Mohms after life.

**3** Contactor can operate up to 125°C in special cases - contact GIGAVAC for details.

**4** See Application Note <u>AN-022</u> for PWM instructions.

 ${\bf 5}$  Operation time is measured at 25°C and includes maximum 7ms bounce.

6 Rated voltage refers to max voltage for which make/break load cycles are provided. Contactor can be used in higher voltage systems. Contact GIGAVAC for more info.